

House Plan Examples



The brick detailing and standing seam accents make this a great rear entry example.



The above image sets an ideal standard for the Texas Tudor Design theme. The chimney detail, brick patterns, and color palette are all strong architectural elements.



The image above is an excellent variation of the top left elevation. By varying colors of materials the same look can easily be accomplished.



In this image the half timbering and multi-paned windows are the highlighted Texas Tudor elements to replicate.



3.9 CONCEPTUAL ELEVATIONS



There are very few front entry lots in Mercer Crossing, but this is a prime example to be used. The brick details, half timbering inlay reinforce the Texas Tudor style.




The multiple Texas Tudor elements include: eyebrow windows, cedar shutters, herringbone brick details, and native building materials.



This is another great front entry elevation. The intricate detail on the chimney and the use of native materials are the very definition of Texas Tudor.



The above townhome elevation includes Standing seam accents, multi-paned windows, half timbering, and an acceptable color palette.



3.9 CONCEPTUAL ELEVATIONS